

Jain Laboratory Instruments







Product Code. JL-MLLE-9171

Control Value Characteristics Trainer

Description

Control Value Characteristics Trainer

The control valve is of linear / Equal % type.

Detail Manual will be provided to conduct experiment.

Digital 4 - 20 mA variable current source is provided to control the I/P converter.

Rota meter is provided to measure the flow rate at which changes as per the valve opening.

Control Valve trainer comprises of globe type control valve $(\hat{A}\frac{1}{2})$ with diaphragm type Pneumatic actuator.

The setup comprises of water pump with necessary flexible piping, Water tank, I to P converter, Air regulator fitted on a table top powder coated metal frame.